Tip 5-To Exit The Edit Mode

MODE

1. Press the [button]. The display of the MD unit will read

UTOC Write?

●REC

2. Press the [button]. The display of the MD unit will momentarily flash

UTOC Writing

After completing the writing of the "User Table of Contents" (or UTOC) the unit will return to the ready mode for further recording or playback.